

Pos.No.	Description	Art. No.
2	Grid lid (hinge 90 mm)	65.002
2 A	Spring lock for grid lid	65.002A
3	Mixer drum incl. mixer gate, complete set	65.003
4	Frame, complete w/wheels etc.	65.004
4 B	Bucket stand	65.004B
4 F	Frame, front - below bucket stand	65.004F
4 L	Frame, front - left side part	65.004L
4 R	Frame, front - right side part	65.004R
4 T	Frame, top/rear part	65.004T
5	Loading wheel (1 stk.), 80 mm, excl. bolt	65.005
5 B	Bolt (1 pc.) for 80 mm loading wheel	65.005B
6	Wheel (1 pc.), 300 mm, excl. bolt	65.006
6 B	Bolt (1 pc.) for 300 mm wheel	65.006B
6 W	Washer (1 pc.) for 300 mm wheel	65.006W
7	Mixer gate incl. bolt etc.	65.007
8	Switch 8.0 Amp. w/thermal circuit breaker & O-discharger ...	65.008
8 K1	Power breaker, straight metal part.	65.008K1
8 K2	Metal bracket for the power breaker's metal part	65.008K2
9	Mixer arm, Side	65.009
10	Mixer arm, Side-base	65.010
11	Mixer arm, Rake	65.011
13	Gear motor 0.75 kW, 1400/30 RPM, 1 x 230 V	65.013
13 G	- Gear only	65.013G
13 M	- Motor only	65.013M
14	Starting capacitor 125 µf	65.014
15	Operating capacitor 25 µf	65.015
17 B	Telescopic leg (1 pc.), rear (excl. wheels)	65.017B
17 L	Telescopic leg (1 pc.), front - left side	65.017L
17 R	Telescopic leg (1 pc.), front - right side	65.017R
17 SB	Bolt and nut (1 pair) for telescopic leg (1 pc.)	65.017SB
19	Safety grid by the mixer gate ved	65.019
21 B	Rubber parts (replacement set, cross joint only)	65.021B
22	Mixer arms, 3 pcs, incl. cross joint	65.022
	Mixer arms, 3 pcs., excl. cross joint	65.022A
30	Discharge chute incl. bolts	65.030
47	Cross joint for mixer arms, rubber, incl. washers and bolts	65.047

Spare Part List - 65 Light, 230V



GB-15.03.17

